



"SMARTLINK COMPANION"
(Voice Pendant)



SLC14
(14 button)



SLC3
(3 button)

USER MANUAL

Table of Contents


1. The SMARTLINK COMPANION	2
2. KIT CONTENTS	2
3. HOME SET-UP	3
3.1 Setting up your SMARTLINK COMPANION	3
3.2 SMARTLINK COMPANION Registration with a DECT/GAP base station	4
3.3 Saving Phone Numbers on Your SMARTLINK COMPANION	4
4. HOW TO USE SMARTLINK COMPANION	4
4.1 Placing calls with speed-dial	4
4.2 Answering incoming calls	4
4.3 Adjusting volume	5
4.4 Ending a call	5
4.5 Recharging your SMARTLINK COMPANION HANDSET	5
4.6 Placing calls on the SMARTLINK COMPANION keypad	5
5. CUSTOMIZING YOUR SMARTLINK COMPANION handset	5
5.1 Adjusting the ring tone	5
5.2 Selecting ring tones on your SMARTLINK COMPANION	6
5.3 Selecting receiver volume	6
6. INDICATORS	6
6.1 Out-of-range indicator	6
6.2 Low POWER INDICATOR	7
6.3 LED color indicators	7
7. DECT Base Station	7
7.1 Page Key	7
7.2 LED - In use LED	7
8. MAINTENANCE TIPS	8
9. SPECIFICATIONS	8
10. COMPLIANCE	9
11. APPENDIX - 1	10
12. APPENDIX - 2	10

1. THE SMARTLINK COMPANION

The SMARTLINK COMPANION is a handy digital enhanced cordless phone you can wear around your neck, tuck into a back pocket or leave beside your bed lamp at night. It goes wherever you go...

Just press the ONE-TOUCH button whenever you want to do any of the following:

- Place a call any time of the day or night,
- Answer incoming calls, and
- Hang up.



Front view

2. KIT CONTENTS


Your kit contains the following:

- 1 SMARTLINK COMPANION handset
- 1 SMARTLINK COMPANION AC adaptor/Charger
- 1 deluxe collar strap
- 1 user manual

**SMARTLINK
COMPANION**



**SMARTLINK
COMPANION Charger**




3. HOME SET-UP

All you need to do is to set up the SMARTLINK COMPANION and subscribe to a DECT/GAP base station.

3.1 SETTING UP YOUR SMARTLINK COMPANION

Perform the following three steps to set up your SMARTLINK COMPANION:

- Flip the power switch to the left using a ballpoint pen.



- Plug the SMARTLINK COMPANION AC adaptor into a wall socket.



- Allow six hours for your SMARTLINK COMPANION to charge the batteries.
- Leave the power switch in the ON position after setting up your SMARTLINK COMPANION.

When the SMARTLINK COMPANION is on, you will see an orange LED light flashing three times per second. The orange light means your SMARTLINK COMPANION is on but has not yet registered with a base station.

The SMARTLINK COMPANION LED light will flash green once every 10 seconds as soon as it connects to a base station, enabling you to place and receive calls.

***Battery life is up to 144 hours in standby mode.
However you should recharge your SMARTLINK COMPANION daily.
Your SMARTLINK COMPANION will beep as soon as battery power is low.***

- **Connection**

Perform the following to connect your SMARTLINK COMPANION™ to a DECT/GAP base station:

Preset the base station to REGISTRATION MODE

(Refer to Installation Manual of Base Station being used)

Dial the numbers below:

→ + * + # + 1 0000 + →

1 is the number of the base station and **0000** is the PIN code for the base station.

Your SMARTLINK COMPANION will register with a maximum of four different DECT/GAP base stations.

- **Selecting a Base Station**

When your SMARTLINK COMPANION is registered with two or more base stations, perform the following to select which one you want to use:

→ + * + 8 + 1 + →

1 is the number of the base station you want.

- **Please Refer to Appendix 2 for details on registering 3 button versions.**

3.3 SAVING PHONE NUMBERS ON YOUR SMARTLINK COMPANION

SMARTLINK COMPANION has a speed-dial memory feature. Just press the ONE-TOUCH button to dial the number stored in memory.

Key in the following to store a new phone number:

(Up to 4 outgoing numbers and 3 Auto-Answer numbers with Caller-ID enabled)

→ + 1 + the number you want to save + →
→ + 2 + the number you want to save + →
→ + 3 + the number you want to save + →

Your SMARTLINK COMPANION handset is now fully installed and connected to a base station.
You can now place and receive calls.

NB: *If more than one number is programmed into unit, then multiple presses of the One-Touch button will rotate between numbers when call is in progress.*

- **Please Refer to Appendix 1 for more detail on programming keys.**

4. HOW TO USE SMARTLINK COMPANION

4.1 PLACING CALLS WITH SPEED-DIAL

All you need to do is:

- Press the ONE-TOUCH button to place a direct call to the number you saved in the SMARTLINK COMPANION handset memory.

4.2 ANSWERING INCOMING CALLS

When your SMARTLINK COMPANION rings, all you need to do is:

- Press the ONE-TOUCH button once.

4.3 ADJUSTING VOLUME

If you can't hear your conversation partner comfortably, you will need to raise or lower the volume on your SMARTLINK COMPANION handset as follows:

- Press the  key until you find the right volume.

4.4 ENDING A CALL

- Hold down the ONE-TOUCH button on the front of your SMARTLINK COMPANION handset until you hear a beep.

4.5 RECHARGING YOUR SMARTLINK COMPANION HANDSET

You should recharge your SMARTLINK COMPANION handset daily as follows:

- Connect the handset to the AC adaptor.

Your SMARTLINK COMPANION will beep as soon as recharging starts. A red LED light will flash once every two seconds to confirm that recharging is in progress.

4.6 PLACING CALLS ON THE SMARTLINK COMPANION KEYPAD

Perform the following to place an individual call using your SMARTLINK COMPANION keypad:

- Press  to obtain a dial tone.
- Dial your number.
- Press  to hang up at the end of your call.

5. CUSTOMIZING YOUR SMARTLINK COMPANION HANDSET

You can customize your SMARTLINK COMPANION using the keypad on the back of the handset.



SLC14
Back view



SLC3
Please refer to SmartLink for programming of SLC3 (3 button)
(In-house programming required)

5.1 ADJUSTING THE RING TONE

For greater hearing comfort, perform the following to adjust the ring tone volume on your SMARTLINK COMPANION handset:

- Press 
- Then press  and **4**
- Now press **0**, **1**, **2** or **3** (you will hear each tone as you press each key). The **0** key is for silent mode.
- Press  to validate your choice. You will then hear a beep to confirm your selection.

5.2 SELECTING RING TONES ON YOUR SMARTLINK COMPANION

Perform the following to personalize your ring tone:

- Press 
- Then press  and **3**
- Now press **1, 2, 3, 4** or **5** (you will hear each tone as you press each key)
- Press  to validate your choice. You will then hear a beep to confirm your selection.

5.3 SELECTING RECEIVER VOLUME

Perform the following to adjust the volume of the SMARTLINK COMPANION built-in speaker:

- Press  once.
- Now press  again to adjust the volume

Your SMARTLINK COMPANION has six volume settings (0-1-2-3-4-5). You access them by repeat pressing of the  key. You will hear a beep whenever you have reached the minimum and maximum settings.

Example: Press the  several times and your SMARTLINK COMPANION will show: 3-4-5-(Beep)-4-3-2-1-0-(Beep)-1-2-3-4 and so on.

6. INDICATORS

6.1 OUT-OF-RANGE INDICATOR

If you move out of range of the base station, your SMARTLINK COMPANION transmission and reception will suffer. A beep and LED light will alert you whenever you stray too far.

- **Maximum Range Indicators**

Your SMARTLINK COMPANION handset will beep twice whenever it is almost out of range. Beeping will continue until you are comfortably back within operating range again.

When you hear the double beep, move back towards the base station. If you continue moving away from it, you will go offline. The LED on your SMARTLINK COMPANION will then blink in orange three times per second to show that you can no longer place or receive calls.

- **Disconnection from Base Station**

If your SMARTLINK COMPANION is out of range, you will hear the beeps and see the LED blink in orange three times per second. All you need do is move your SMARTLINK COMPANION closer to its base station.

6.2 Low POWER INDICATOR

Your SMARTLINK COMPANION needs adequate battery power to function properly. When the battery runs low, you will hear and see the following:

- One beep every three seconds when power is low, and
- The LED light blinks in red once every 5 seconds.

6.3 LED COLOR INDICATORS

<u>Handset Status</u>	<u>Colour</u>	<u>Blink Rate</u>
<i>Online</i>	<i>Green</i>	<i>Once every 10 seconds</i>
<i>Call in progress</i>	<i>Green</i>	<i>Steady light</i>
<i>Low battery</i>	<i>Red</i>	<i>Once every 5 seconds</i>
<i>Recharge underway</i>	<i>Red</i>	<i>2 times per second</i>
<i>Offline</i>	<i>Orange</i>	<i>3 times per second</i>

7. DECT BASE STATION

The base may be any DECT/GAP Base station. Simply ensure the nominated base station is plugged into your phone line and mains power. Then check your SmartLink Companion into the base station to instantly start making calls on your SmartLink Companion. (*Refer to Installation Manual of the Base Station being used*)

You may locate your SmartLink Companion anytime by pressing the “Page” button found on your Base Station.

7.1 PAGE KEY

The Page key on the Base may be used to send a page to the SmartLink Companion. The handsets will ring for 1 minute unless the page key is pressed again on the base or a key is pressed on any locked handset.

Usual operation of existing base stations in the market:

Key action	SMARTLINK COMPANION action
Short press (<5 s)	Send a page to handsets
Long Press (>=5s)	Enter subscription mode (in use LED will flash)

7.2 LED - IN USE LED

The LED on the Base unit usually indicates different modes of operation.

<u>Action</u>	<u>LED state</u>
Standby mode	ON
In call	Flashing
Key pressed (<5s)	ON
Subscription mode	Flashing

To change the ringer melody or volume of your Base, please refer to Installation manual of the Base Station being used.

8. MAINTENANCE TIPS

- Clean your SMARTLINK COMPANION with a soft damp cloth only. Do not use aerosol sprays.
- Avoid contact with any liquids.
- It is normal for batteries to warm up during recharge.
- Do not use any recharging device except the AC adaptor supplied in your SMARTLINK COMPANION kit. Never try to open your SMARTLINK COMPANION handset to avoid creating an electrical hazard to your health. Return it to our after-sale support service for any needed repairs.
- Do not use the handset in any room or area that presents a risk of combustion or explosion.

9. SPECIFICATIONS

- **Standard :** DECT (**D**igital **E**nhanced **C**ordless **T**elecommunications)
GAP (**G**eneric **A**ccess **P**rofile)
- **Frequency range:** 1880 MHz to 1900 MHz
- **Number of channels:** 120 duplex channels
- **Modulation:** GFSK
- **Speech coding:** 32 kbit/s
- **Emission power:** 10 mW (average power per channel)
- **Range:** Up to 300 metres in open space
- **Base power supply:** 220-240 V / 50 Hz for the base
- **Handset power supply:** rechargeable battery 37AAAM, Ni-mH 370mAh
- **Battery capacity:** Up to 6 days standby, up to 3.5 hours talk time
- **Charge up time:** Approx 6 hours
- **Temperature range:** +5 °C to +45 °C
- **Dimensions:** 57*19 mm (diameter*thickness)

10. COMPLIANCE

The phone complies with the following standards

Part	Standard
DECT Radio	TBR 6
DECT acoustics	TBR 10 – 3 rd edition
DECT GAP	TBR 22

SMARTLINK COMPANION complies with relevant EC standards

***FOR FURTHER DETAILED INFORMATION PLEASE REFER TO
SMARTLINK REGARDING TECHNICAL INSTALLATION MANUAL.***

WARNING:

This voice pendant is not designed for making emergency telephone calls during a power fail unless some form of battery back up is available at the base station.

11. APPENDIX - 1




Figure 1 : keypad layout

Some keys have more than one usage depending on the SmartLink Companion's state (*standby, in call, menu mode*). The following table gives all the possible actions for each key.

KEY	Action		
	Standby Mode	Menu Mode	During Call
KEY_PHONE	Go in talk mode		Hang up
KEY_MENU/ KEY_VOL	Settings	Validate	Speaker Volume (in call)
KEY_0		Dial 0	Dial 0
KEY_1		Dial 1	Dial 1
KEY_2		Dial 2	Dial 2
KEY_3		Dial 3	Dial 3
KEY_4		Dial 4	Dial 4
KEY_5		Dial 5	Dial 5
KEY_6		Dial 6	Dial 6
KEY_7		Dial 7	Dial 7
KEY_8		Dial 8	Dial 8
KEY_9		Dial 9	Dial 9 (short press)
KEY_PAUSE			Pause (long press)
KEY_STAR			Dial * (short press)
KEY_R			R (long press)
KEY_HASH			Dial # (short press)
KEY_INT	Intercom		Intercom (long press)

Figure 2 : Keypad description

Short press is less than 3 seconds. **Long press** is more than 3 seconds.

12. APPENDIX - 2

To register a 3 button SmartLink Companion, use the following steps:

- Preset the base station to registration mode.
- Press and hold down “-“ (*minus key*) and switch ON the SmartLink Companion.
- Press “+” (*plus key*) and then press the Phone symbol button 5 times, each time holding the key down for more than three seconds until a beep is heard. (The handset number is automatically defined by the base.)



© Copyright SmartLink International Pty Ltd
August 2005

475 Nepean Highway
Brighton VIC 3186 AUSTRALIA

Tel: +61 3 9596 0770 Fax: +61 3 9596 8195

Email: smartlink@smartlink.com.au

Web Site: www.smartlink.com.au

To the best of our knowledge, the information contained in this manual is correct at the time of print. SmartLink International Pty Ltd reserve the right to make changes to the features and specifications at any time without prior notice in the course of product development.